










- Ⓓ Montage- und Bedienanleitung
- ⒸN 安裝及操作指南
- ⒸZ Návod k instalaci a k použití
- Ⓔ Instrucciones de montaje y de manejo
- Ⓕ Instructions de montage et mode d' employ
- ⒼB Installation and operating instructions
- ⒼR ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗΣ
- Ⓕ Szerelési és használati utasítás
- Ⓕ Istruzioni di montaggio e per l'uso
- ⒼL Montagehandleiding en Gebruiksaanwijzing
- ⒼL Instrukcja montażu i obsługi
- ⒼO Instrucțiuni de montaj și utilizare
- ⒼU Руководство по монтажу и эксплуатации
- ⒼK Návod na montáž a obsluhu



1.






2.





	1	2	3
53 811	G 3/4	80 - 110mm	max Ø55mm

1.






2.





	2	3
29 757	60 - 110mm	max Ø55mm

1.



2.



	2	3
29 747	60 - 110mm	max Ø55mm